

TRS

C H FERRULES INSTALLATION INSTRUCTIONS

CH Ferrules are designed to press-fit into each end of heavy duty cable housing. C H Ferrules not only provide friction free entry and exit of the cable but they also secure Teflon Liner inside the housing. No more flaring hassles for the Teflon Liner!

Cut cable housing to desired length. Grind flat on belt sander. Polish outside edge. Deburr inside edge with stone bit. Polish inside edge with rubberized abrasive tip. Push C H Ferrule into end of housing, if more pressure is needed hold against edge of bench and push until C H Ferrule is completely flush with cable housing.

Note: There is always a bit of variation in the cable housing, if C H Ferrule is too tight use a block of wood to tap C H Ferrule into position. Hit square to face of the C H Ferrule to avoid damage.

Slide Teflon Liner into housing until it contacts C H Ferrule. Make a mark on Teflon liner at edge of housing, pull Teflon liner out at equal to total length of C H Ferrule then cut off with a razor knife. Install final C H Ferrule.

For questions please call 1-800-279-1865

