

HAMMERHEAD STRAP REPLACEMENT INSTRUCTIONS

- 1) Remove the two strap fastening screws, remove all remnants of old strap which may remain inside the strap cavity.
- 2) Slide the new strap into the strap cavity, make sure it goes to the very bottom of the cavity. Use a 7/64" drill bit to pre-drill new screw holes through the new strap. Hold the strap in place, insert the drill bit into one of the existing holes in the Hammerhead Body and carefully drill down through the strap. Be careful to not go too deep into the Hammerhead Body, just enough to go through the strap.
- 3) Keep holding the strap in place while installing the strap fastening screws, do not over-tighten the screws, tighten until head of each screw slightly compresses into the Hammerhead Body.

Please call TRS with any questions at 1-800-279-1865